

**Issue Summary** Serial Number Location

**Applies To** All treadmills, cycles, ellipticals, and cross-trainers

<b>Detailed Problem Description</b>	Where to locate the serial number on different types and models of equipment
-------------------------------------	--

Equipment	Models	SN Location
Treadmill	ALL	Front cover or frame, near the power switch
Upright Cycle	C51U	Rear frame vertical post, facing the cover
	C52U	
	C53U	
	C530U	
	C570U	
	C580U	
	C5200U	Front cover
Recumbent Cycle	C51R	Slanted vertical frame, near rear handle
	C52R	
	C53R	
	C530R	
	C570R	Front cover
	C580R	
	C5150	
Elliptical Trainer	805P	Rear cover, near power switch
	807P	
	E82	
	E820	
	E83	At rear, near power cord.
	E86	
	E8300	Under rear cover on right side of frame; look in the cover opening for the glide rails
	E870	
	E880	
Cross Trainer	XT20	On the rear frame
	XT50	Rear cross support handlebar