

Issue Summary Motor Cover Removal

Applies To Treadmill models T630, T650 and T650M

Detailed Problem Description

Step by step instructions on removing the motor cover from the T630 and T650/M treadmills.

Procedure Overview

1) Motor Cover Removal

1) Motor Cover Removal

- A) Disconnect power and allow 2 – 3 minutes for equipment to fully discharge before performing electrical work to avoid personal injury and/or damage to equipment.
- B) The procedure is the same for left and right sides of the equipment. Follow the procedure through for one side and repeat on the opposite side.
- C) Slide the sweat guard up the pedestal.
- D) Push the pedestal Cover upward until it unsnaps. Remove the pedestal cover by lifting up and out.
- E) Locate the rubber cap on the side cover (just to the rear of the venting on the side cover.) Using a screwdriver, press the rubber cap inward to remove it. The rubber cap will fall to the floor. (See Illustration #1)
- F) Loosen, but **do not remove** the retaining screw exposed by removing the rubber cap in Step D.
- G) **Remove** the motor cover retaining screw near the rear of the pedestal base. (See Illustration #2)
- H) **Remove** the motor cover retaining screw near the front of the pedestal base. (See Illustration #3)
- I) Perform Steps C → H on the opposite side of the equipment.
- J) Lift the motor cover from the equipment.
- K) Reverse the procedure on both sides to replace the motor cover.

Illustration #1



Illustration #1

Illustration #2



Illustration #2

Illustration #3



Illustration #3